



Instructions For Baptistry Window Installation

Materials Needed:

- 1 – Tube sealant (factory provided)
- 1 – Knife or scissors and a nail (to open sealant tube)
- 1 – Caulking Gun
- 1 – Clean cloth rags or paper towels
- 1 – Acetone (hint: inexpensive fingernail polish remover is acetone)
- 1 – Pressure Blocks (between wall of baptistry & window)
- 2—Small clamps with pads

1. Prepare Surfaces

- A. Carefully remove protective paper from window.
- B. Using acetone and a rag, clean the channel where the window will seat.
- C. Using acetone and a rag, clean the edge of the window.
- D. The window and the seating area should now be free of dirt and wax.

2. Apply Sealant

- A. Cut 1” off the tip of the sealant tube. Use a nail to puncture the seal.
- B. Apply a bead 1/2” to 3/4” wide along the surface of the baptistry where the window will seat as shown in Figure A.

3. Install the Window

- A. Firmly press the window into place as shown in Figure A.
- B. View the sealant through the window. It should spread evenly over the entire contact surface. There should be few or no air bubbles.
- C. Apply firm pressure all along the contact area, working out any air bubbles.
- D. Use a clean rag to wipe away any excess.
- E. Maintain a constant pressure on the window for a minimum of 12 hours using pressure blocks as shown in Figure B.

4. Finish Out

- A. After 12 hours, remove the pressure blocks from the window.
- B. Run a small bead or sealant on the inside and outside of the window.
- C. Smooth out the bead for a clean, uniform appearance.
- D. Allow sealant to dry for 24 hours before filling.

Instructions
For
Baptistry Window Installation

