

Reassembly for Split Filament Wound Fiberglass/Resin-infused Columns

Column shafts will arrive split in half with tabs fastened to column with 1" grabber screws (see drawing).

- Separate column halves by removing 1" grabber screws from one side of column seam. Back grabber screws out from the other half to allow tabs to separate from the column. Apply high quality polyester adhesive (see detail A). Tighten grabber screws on tabs.
- Position tabbed half section around post or support.
- Align other half section to tabbed section and join together with high quality polyester adhesive and screws. Strap clamps may be useful.
- After adhesive cures, (follow recommended cure time) remove the clamp or straps and screws. Fill the seam with polyester type bondo or filler and sand smooth.
- After sanding and removing dust, column is ready for finishing, priming and painting.

NOTE: Column shafts are fully load bearing. Splitting and tabbing is a service that we provide for you. If you choose to split shafts, our warranty is void. Always keep shafts joined together until ready for assembly

